

# KBSW180158 Breakout kit

breakoutbreakout3.06.0breakout



breakout 3.0 breakoutVer3.0 6.0 breakout R06.


### Breakout 3.0

Breakout 3.0  
Breakout 3.0 SDP mini  
UARTUSB x 1x 3USB


### Breakout 6.0

Breakout 6.0  
SDP mini  
(:  
USB Type B


1. J16J14J14



hexIARworkspace:Release\_Rev6breakout 6.0hex




2. UARTUSBGNDTXRXJ15GNDJ14J16TXTXRXRX




! breakout  
J16

1. J16J16




2. usb type BJ7



! breakout  
J16

### 3. Breakout FlyMCU115200



### 4. J16breakout 3.0 J14breakout